TACRIP P-D

Single ribs in accordance with the German standard for the installation of tactile guide strips in indoor areas



TECHNICAL DIMENSIONS AND PRODUCT VARIANTS

Material	[Polyurethane]
Surface	[smooth], [chequered]
Colour	white, black, grey
Length	29.5 cm
Height	3.3 mm
Width mm	16 mm

PRODUCT VARIANTS

Ident	Height	Surface	Colour	Length
TRPG 1633-3 B	3.3 mm	chequered	black	29.5 cm
TRPG 1633-3 K	3.3 mm	chequered	black	29.5 cm
TRPG 1633-3 SK	3.3 mm	chequered	black	29.5 cm
TRPG 1638-3 B	3.3 mm	chequered	grey	29.5 cm
TRPG 1638-3 K	3.3 mm	chequered	grey	29.5 cm
TRPG 1638-3 SK	3.3 mm	chequered	grey	29.5 cm
TRPG 1630-3 B	3.3 mm	chequered	white	29.5 cm
TRPG 1630-3 K	3.3 mm	chequered	white	29.5 cm
TRPG 1630-3 SK	3.3 mm	chequered	white	29.5 cm
TRP 1633-3 B	3.3 mm	smooth	black	29.5 cm
TRP 1633-3 K	3.3 mm	smooth	black	29.5 cm
TRP 1633-3 SK	3.3 mm	smooth	black	29.5 cm
TRP 1638-3 B	3.3 mm	smooth	grey	29.5 cm
TRP 1638-3 K	3.3 mm	smooth	grey	29.5 cm
TRP 1638-3 SK	3.3 mm	smooth	grey	29.5 cm
TRP 1630-3 B	3.3 mm	smooth	white	29.5 cm
TRP 1630-3 K	3.3 mm	smooth	white	29.5 cm
TRP 1630-3 SK	3.3 mm	smooth	white	29.5 cm

Data sheet Accessories

Please note: For technical reasons, tolerances in color effects of the materials and print are possible.
All information is based on the best of our knowledge and belief. No guarantee can be derived from this.
We reserve the right to any technical changes if they are in the interest of progress or if they are production-related.

Self adhesive.
Adhesive: 3M.
For indoor areas on all floors except carpet.

Rib height: 3.3 mm
Rib length: 295 mm
Rib width: 16 mm
Rib surface: chequered
Slip resistance class: R10

Templates for standard installation of the single ribs are available as accessories.

PROPERTIES

Self adhesive.
Adhesive: 3M.
For indoor areas on all floors except carpet.

Rib height: 3.3 mm
Rib length: 295 mm
Rib width: 16 mm
Rib surface: chequered
Slip resistance class: R10

MATERIAL

Polyurethane

PROCESSING

1. The substrate must be cleaned. Any contaminants such as release agents, preservatives, grease, oil, dust, water, old adhesives/sealants and other residues that could impair adhesion must be completely removed.
2. Mark the area where the film is to be placed.
3. Stick the template in the desired position on the floor.
4. We recommend using two connected templates (tongue and groove) at the start.
5. Remove the protective film from the back of the stud and stick it to the desired position using the template.
6. Continue with further studs as described in point 5 until the template is completely filled.
7. Press the studs down further by carefully walking over them with your feet.
8. Remove the template and press the nubs again by carefully walking over them with your feet.
9. If necessary, continue with step 3.

The generally accepted rules of technology and tiling must be observed. Suitability for use with mechanical and chemical resistance must always be checked in each individual case.

Please note: For technical reasons, tolerances in color effects of the materials and print are possible.
All information is based on the best of our knowledge and belief. No guarantee can be derived from this.
We reserve the right to any technical changes if they are in the interest of progress or if they are production-related.