




DURASTEP WOOD

Stair nosing profile with a solid wood step surface



TECHNICAL DIMENSIONS AND PRODUCT VARIANTS

Material	[Aluminium],[Wood]
Surface	[smooth]
Colour	oak
Length	100 cm, 250 cm
sight width	50 mm
Height	13.5 mm, 10 mm
Width mm	50 mm

PRODUCT VARIANTS

Ident	Height	Surface	Colour	Length
DSTWP 1001/100	10 mm	smooth	oak	100 cm
DSTWT 1001/100	10 mm	smooth	oak	100 cm
DSTWP 1001/250	10 mm	smooth	oak	250 cm
DSTWT 1001/250	10 mm	smooth	oak	250 cm
DSTWP 1201/100	13.5 mm	smooth	oak	100 cm
DSTWT 1201/100	13.5 mm	smooth	oak	100 cm
DSTWP 1201/250	13.5 mm	smooth	oak	250 cm
DSTWT 1201/250	13.5 mm	smooth	oak	250 cm

MATERIAL

Aluminium can be used wherever medium mechanical stress is to be expected. Contact with alkaline materials (e.g. tile adhesive) can lead to discolouration, which is difficult to remove afterwards. High humidity during the drying phase can intensify this process. Always wipe tile adhesive or grout off visible surfaces immediately with plenty of water, then wipe dry and ensure good ventilation.

American oak

The suitability with regard to mechanical and chemical resistance must always be checked on a case-by-case basis.

PROCESSING

Please note: For technical reasons, tolerances in color effects of the materials and print are possible. All information is based on the best of our knowledge and belief. No guarantee can be derived from this. We reserve the right to any technical changes if they are in the interest of progress or if they are production-related.



1. Select the profile according to the tile thickness.
2. Apply tile adhesive with a notched trowel.
3. Press the profile into the adhesive bed and align it.
4. Fill the fixing flange completely with adhesive.
5. Press the tiles firmly into place and align them so that they are flush with the top edge of the profile. Lay the tiles so that they are completely covered.
6. Cut the profile to mitre for corner formation. Seal the mitre joint with a neutral cross-linked silicon.
7. Leave a 1-2 mm joint between the profile and the tiles.
8. Fill the space between the tiles and the profile completely with joint mortar.

Protect visible surfaces from contact with tile adhesive or grout and clean immediately with a cloth and clear water if necessary. Then rub dry.

The generally accepted rules of technology and tiling must be observed. Suitability for use with mechanical and chemical resistance must always be checked in each individual case.

CARE

Aluminium does not require any special care. If necessary, it can simply be cleaned with clear, clean water and a few drops of washing-up liquid. Then wipe dry.

Avoid using acidic and abrasive cleaning agents.

To properly care for American oak, regular cleaning and occasional treatment with oil or wax is recommended.

Dust and dirt should be removed regularly with a soft, dry cloth or a slightly damp cloth, always wiping off any excess water. Make sure to dry the surface thoroughly afterwards.

For more intensive cleaning, you can use a diluted vinegar and water solution or a special wood soap.

Do not use harsh cleaning agents, abrasives or those containing alcohol, ammonia or silicon, as these can damage the wood.

Special wood oils for oak can be applied with a cloth and should be removed after approx. 15-20 minutes.

Wax can also be applied to care for and protect the wood. Here too, excess wax should be removed after the application time.

The frequency of oil or wax treatments depends on the use and wear of the wood. For heavy use, annual or semi-annual treatment may be advisable.

Please note: For technical reasons, tolerances in color effects of the materials and print are possible.
All information is based on the best of our knowledge and belief. No guarantee can be derived from this.
We reserve the right to any technical changes if they are in the interest of progress or if they are production-related.